

For apple, android & most usb-powered devices

All product and company names are trademarks or registered trademarks of their respective rights holders. Use of the marks does not imply any affiliation with, or endorsement by, the respective rights holders. iPhone is a registered trademark of Apple Inc. Android is a registered trademark of Google LLC.

INSTRUCTIONS

Model: PB7

INSTRUCTION MANUAL

Please keep observed safety notes before use

Technical data

Model: PB7

Input: Micro-USB 5V \approx 2.4A Max or Type-C 5V \approx 3.0A Max Class III

Output: USB-A 5V \approx 2.4A Max

Type-C 5V \approx 3.0A Max

Total 5V \approx 5.4A Max

COMPATIBILITY

Duracell Powerbank is compatible with most Smart Phones, tablets and most USB-powered devices.

SAFETY & SUPPORT

IMPORTANT SAFETY INSTRUCTIONS

WARNING – When using this product, basic precautions should always be followed:

- Read all the instructions before using the product.
- To reduce the risk of injury, close supervision is necessary when the product is used near children.
- Do not expose Powerbank to rain or snow.
- Use of a faulty charger to charge this Powerbank may result in a risk of fire or injury to persons.
- Do not use the Powerbank in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.
- Do not use the Powerbank if it is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not disassemble the Powerbank.
- Do not expose the Powerbank to fire or excessive temperature. Exposure to fire or temperature above 60°C may cause explosion.
- This Powerbank has no serviceable parts. Call DURACELL if you experience any problems.
- Do not operate where aerosol (spray) products are being used or where oxygen is being administered
- Only set or store on clean dry surfaces. Do not place on surface that is wet from water or cleaning solvents.
- Do not operate in a closed environment, such as a pocket, backpack or carry case.

For more information regarding our Product line, please visit:

 www.duracell.info

For service or repair - do not return this unit to the retailer. Contact Duracell Consumer Relations, details on packaging.

BATTERY SAFETY INFORMATION

- Do not dismantle, open or shred the battery.
- Do not expose the battery to heat or fire
- Avoid storage in direct sunlight.
- Do not short-circuit the battery.
- Do not subject the battery to mechanical shock.
- Keep the battery out of the reach of children.
- Keep the battery clean and dry.
- Do not leave battery on prolonged charge when not in use
- Duracell Powerbank has advanced technology that halves the output current when it predicts overheating.

BATTERY STORAGE

- Store in a cool dry place.
- Store charged at regular ambient temperatures, 25°C \pm 5°C.

BATTERY CAUTION

The lithium rechargeable battery used in this charging device may present a risk of fire or chemical burn if mistreated. Do not disassemble, short circuit, crush, expose to heat above 60°C or incinerate. Do not operate outside of its operating temperature range of 0°C to 40°C. Misusing or incorrectly connecting the charging device may cause electric shock to users and damage equipment. Read instructions carefully. The Powerbank may become warm and may reach 50°C under extended high-power operation. During operation, keep the charging device away from materials that may be affected by these temperatures. Follow manufacturer instructions.


CORRECT DISPOSAL FOR THIS CHARGING DEVICE

Please follow any local requirements to recycle this lithium rechargeable device.




Manufacturer: Duracell Singapore Pte Ltd.

Address: 11 North Buona Vista Drive, #16-08, The Metropolis Tower 2, Singapore 138589



Charging your POWERBANK

Charging your device



Power/battery indicator