



Model No CX1500

Automatic Universal Lithium Ion Video/Camcorder/Digital Camera PLUS AA/AAA NiCd/NiMH Battery Charger with LCD display

- This universal battery charger comes attractively packaged in a clam shell than can be hung or free standing. The unit has a built in base plate & includes additional adaptor plates that will fit the majority of major brand lithium ion battery packs for Video/Camcorder/Digital Cameras.
- Adaptor Plate now included for charging 1 to 4 AA or AAA size NiCd or NiMH batteries.
- Charging time - standard batteries will take around an hour to charge & high capacity batteries from 2-6 hours dependant on the battery capacity.
- Features LCD charge indicator display.

Input: 12VDC via car cigarette lighter plug or 100-240VAC power supply included.

Output: auto voltage detect 8.4VA. SAA, GS, UL, CE approved.

The standard package includes the CX1500 charger, world voltage 100V-240V switch mode AC/DC adapter, cigarette lighter plug cord, battery adaptor plates, user manual.



Mi Master Instruments

Sydney 33-39 Sloane St Marrickville NSW 2204

Phone (02) 95191200 Fax (02) 95194604 Email sales@master-instruments.com.au

Melbourne Unit 13 107 Heatherdale Rd Ringwood VIC 3134

Phone (03) 98726422 Fax (03) 98726466 Email vic@master-instruments.com.au

Available from

The CX1500 charger comes with adaptor plates to suit most Lilon camcorder & digital camera battery packs as well as an adaptor plate for 1 to 4 AA or AAA NiCd or NiMH batteries.

To check compatibility for lithium ion battery packs please check the guide below.

UNIVERSAL Li-ION BATTERY CHARGER COMPATIBILITY CHART

Brand	Battery	Charge By	Brand	Battery	Charge By
CANON®	BP-2L12/14	Adapter Plate A	KODAK®	KLCI-3000	Adapter Plate A
	BP-3LCL	Universal Plate		KLIC-3000	Universal Plate
	BP-406/412/422	Adapter Plate D		KLIC-5000/5001	Universal Plate
	BP-511/512/522/535	Base Unit		KLIC-7000	Universal Plate
	BP-608/617	Adapter Plate A	KONICA®	DR-LB1/LB4	Universal Plate
	BP-911/914/915/941	Base Unit	KYOCERA®	BP-780S	Universal Plate
	BP-924/927/930/945	Base Unit		BP-800S	Universal Plate
	NB-1L	Adapter Plate C		BP-1000S	Universal Plate
	NB-1LH	Universal Plate	MINOLTA®	DR-LB1	Universal Plate
	NB2F12	Adapter Plate C		NP-200/400/600	Universal Plate
	NB-2L	Universal Plate	NIKON®	EN-EL1	Adapter Plate C
	NB-2LH	Universal Plate		EN-EL2/EL3/EL5	Universal Plate
	NB-3L	Universal Plate	OLYMPUS®	BP-LM1	Universal Plate
				LI-10B/12B	Universal Plate
CASIO®	NP-20/30/40	Universal Plate	PANASONIC®	PS-BLM1	Universal Plate
FUJI®	DR-LB4	Universal Plate		AG-BP15P	Base Unit
	NP-30/40/60	Universal Plate		AG-BP25	Base Unit
	NP-80	Adapter Plate A		CGA-DU07	Universal Plate
	NP-100/120	Universal Plate		CGA-DU14	Universal Plate
HITACHI®	VM-BPL13/27/30/60	Base Unit		CGA-DU21	Universal Plate
	VM-E330/535	Base Unit		CGA-S001E	Universal Plate
	VM-N520	Base Unit		CGA-S002	Universal Plate
	VM-NP500	Base Unit		CGA-S003A/1B	Universal Plate
JVC®	BN-507/514	Adapter Plate C		CGP-110E/120E	Adapter Plate B
	BN-V101	Universal Plate		CGP-145/165/285	Adapter Plate B
	BN-V107/114	Adapter Plate D		CGP-D14/16/21/28	Adapter Plate B
	BN-V214/207	Adapter Plate C		CGR-101	Universal Plate
	BN-V306	Universal Plate		CGR-602A	Universal Plate
	BN-V312U	Universal Plate		CGR-B202A	Base Unit
	BN-V408/416/428	Base Unit		CGR-D08A	Adapter Plate B
	BN-V607/615/628	Adapter Plate B		CGR-D120	Universal Plate
	BN-V712/714	Adapter Plate A		CGR-D120/D110	Adapter Plate B
	BN-V812/814	Base Unit		CGR-D16A	Adapter Plate B
	BN-V907	Adapter Plate B		CGR-D210/220/D320	Adapter Plate B
	J-1723	Adapter Plate B		CGR-D220	Universal Plate
	BN-V312	Universal Plate		CGR-D28A	Adapter Plate B
				CGR-D53A	Adapter Plate B
				CGR-S101A	Universal Plate
				CGR-S301A	Universal Plate

All brands are the property of their respective owners.

UNIVERSAL Li-ION BATTERY CHARGER COMPATIBILITY CHART

Brand	Battery	Charge By	Brand	Battery	Charge By
PANASONIC®	CGR-S302A	Universal Plate	SHARP®	BT-L1/L1U	Adapter Plate A
	CGR-S602	Adapter Plate B		BT-L12/L11/L22	Adapter Plate A
	CGR-S602A	Universal Plate		BT-L2/L2U	Adapter Plate A
	CGR-S602E	Adapter Plate B		BT-L221/L441/L241/L41	Adapter Plate B
		Universal Plate		BT-L226	Universal Plate
	CGR-V14/26	Adapter Plate B		BT-L31	Adapter Plate C
	CGR-V610/620E	Adapter Plate C		BT-LS222/LS442	Adapter Plate B
	DMW-BC7	Universal Plate		VR-BL71	Adapter Plate A
	DMW-BCA7	Universal Plate		VR-BL72	Adapter Plate C
	DMW-BL14	Universal Plate		VR-BL75	Adapter Plate A
	DMW-BM7	Universal Plate		VR-BL81	Adapter Plate A
	PV-BP8	Adapter Plate B		VR-BL91	Adapter Plate B
	PV-DBP5	Base Unit	SONY®	LIP-10	Universal Plate
	VW-VBA05	Universal Plate		NP-500/520	Base Unit
PENTAX®	VW-VBA10	Universal Plate		NP-F10/20/30	Base Unit
	VW-VBAP10	Universal Plate			Adapter Plate B
	VW-VBD07	Universal Plate		NP-F100/200/300	Base Unit
	VW-VBD1 / E	Base Unit		NP-F330	Base Unit
	VW-VBD14	Universal Plate		NP-F530	Base Unit
	VW-VBD2	Base Unit		NP-F550/F570	Base Unit
	VW-VBD21	Adapter Plate B		NP-F720/F730	Base Unit
		Universal Plate		NP-F730H	Base Unit
	VW-VBD23/24	Adapter Plate B		NP-F750/F750SP	Base Unit
	VW-VBP10	Universal Plate		NP-F930	Base Unit
				NP-F950/F960	Base Unit
				NP-FC10/FC11	Base Unit
				NP-FF50/70	Base Unit
				NP-FF51/71	Base Unit
POLAROID®	PR105DG	Universal Plate		NP-FM50/70/90	Base Unit
RCA®	PR-110DG	Universal Plate		NP-FP50/70/90	Base Unit
	PR111DG	Universal Plate		NP-FR1	Universal Plate
RICOH®	DB-30/40/43	Universal Plate		NP-FS11/21/31	Base Unit
SAMSUNG®	NP-40	Universal Plate			Adapter Plate B
	SB-L160/L320/L480	Base Unit			Universal Plate
SANYO®	DB-L10/L20	Universal Plate		NP-F1	Base Unit
	UR-211	Universal Plate		NP-QM51/71/91	Base Unit
	UR-421	Adapter Plate C	THOMSON®	BAT600	Base Unit
	VM-LC100	Universal Plate	TOSHIBA®	PDR-BT1/BT2	Adapter Plate A
SHARP®	AD-S30BT/S31BT	Universal Plate		PDR-BT3/BT9	Universal Plate
	AD-T50BT/T51BT	Universal Plate			

All brands are the property of their respective owners.